

Part # 6035-6037 Detex Kit No Lock Box



Install mounting plate to inside of gate by using six tek-screws.



Install subassembly onto mounting plate using **outside** holes for screws. Subassembly should be 2 1/2" from edge of plate.



Depress push pad and install exit bar on back plate subassembly.



Install cover.



Install back cover using sheet metal screws or 1/4" x 1" machine screw with nut.



Adjust so that exit bar latch hits strike.



After latch bracket is adjusted properly, attach to post with tek-screws.



Receiver must act as a gate stop.